

# pmsf.txt

This file contains a selection of SUBIDs of a HYPE model domain, and is used to run an area of interest of an existing model setup separately. The name “pmsf” is short for “partial model setup file”.

The file is placed in the same folder as [info.txt](#). To run a partial model with the SUBIDs given in *pmsf.txt*, use code `submodel` in *info.txt*.

SUBIDs provided in the file must represent “complete basins”, i.e. include all upstream sub-basins and also all basins linked through irrigation sources in [MgmtData.txt](#) or through regional aquifers in [AquiferData.txt](#).

*pmsf.txt* are simple text files with the total number of sub-basins in the area of interest written in the first line, and whitespace-separated SUBIDs listed from row 2. There is no limit in number of rows with SUBIDs (line breaks are treated as whitespace), and SUBIDs can be listed in any order. SUBIDs listed must be a selection of those provided in [GeoData.txt](#)).

Example for a *pmsf.txt* file structure with 8 sub-basins:

```
8
345 456 464 579 204
496 56 654
```