

Qobs.txt

The *Qobs.txt* file holds observations of discharge for selected points in the model domain. The discharge is assumed to correspond to the outflow from a subbasin. The outflow from a subbasin includes the effect of upstream flows and lakes in the subbasin.

The file is located in the *modeldir* folder set in [info.txt](#). Discharge (m^3/s) is given for consecutive timesteps for selected subbasins for a continuous time period which doesn't need to cover the whole simulation time period. Missing values is denoted -9999.

The first row includes a text string (e.g. date, no spaces allowed) and then subbasin id (*subid* from [GeoData.txt](#)). The first column is date in the format *yyyy-mm-dd [HH:MM]*. If set in [info.txt](#) that *matlab-format* should be read (*readformat 1*) the date format is *yyyymmdd*. The second to last columns are discharge for given subbasins (i.e. not all subbasins required).