

state_saveyyyymmdd[HHMM].txt

State variables can be saved to a file and later used for starting a model simulation from that same point. This can be useful to shorten the simulation time, e.g to skip repeatedly simulate a warm-up period, or to simulate several forecasts after running the model up to date.

State-files are saved for the dates given by `outstatedate` in [info.txt](#). The files are written to the `resultdir` folder. To use a state-file as a starting state `instate` is set in [info.txt](#). A state-file with the date(time) given by `bdate` is expected and used as starting state. The starting state file is expected to be found in the `modeldir` folder. There is one file per time step with saved states:

`state_saveyyyymmdd[HHMM].txt` `yyyymmdd[HHMM]` is the date(time) of the start of simulation (`bdate`). For daily time step only the date is used in the file name.

The first row of the `state_save`-file hold integer codes for what settings were used when creating the file. The settings are checked against the simulation that is started. Most of the settings must be the same for the simulation to start. For instance number of subbasins and classes are checked, as is some model options and time step length. Number of substances simulated (and their internal order) is checked, but it is possible to use a starting state created from a simulation with substances (e.g. NP) to start a simulation of only discharge. It is not possible run a model of only discharge starting from a state created with "substance" T2 though. That is an exception because a T2 simulation turn on lake and river ice calculations and related states. Updating with the AR-method is possible to turn on or off between simulations using starting states.